

Refrigerators, Mortuary (-4°C to +10°C)



TMC2-5-2SD

FEATURES

This Mortuary cabinet is a product from the Fiocchetti Scientific Division. The chamber is constructed inside and out with stainless steel and has 60mm polyurethane insulation. Loading is via two front doors, one located above the other. The refrigeration unit is a packaged assembly which is located on the top of the cabinet. The cool air is forced down through the interior.

The temperature is controlled by a digital controller and has a range of -5°C to +10°C (TMC2-5-2SD) with an optional lower range of -15°C or -25°C (TMC2-25-2SD) available.

The unit is supplied with two roll out stainless steel body trays. For easy loading, an optional hydraulic trolley is available which can lift from 300mm to 1500mm in height.

Features

- Slideout stainless steel trays
- Internal Light
- Lockable doors
- Heavy duty castors supplied standard
- Digital temperature monitor
- Automatic defrosting (drain to be provided)
- Fully insulated chamber and doors

Larger chambers also available to hold 3, 6, 9 or 12 bodies.

ORDER CODE	BODY TRAYS	DIM. EXT HxWxD cm	TEMP. RANGE	APPROX WEIGHT
TMC2-5-2SD	2	188X84X243	-5°C to +10°C	480kg
TMC2-25-2SD	2	188X84X243	-25°C to +10°C	500kg