

MORTUARY REFRIGERATORS

(-5°C TO +10°C WITH -25°C OPTION)

Image: TMC2-5-2SD and side loading model



Mortuary Refrigerators

- Stainless steel internal and external construction
- Two models available - front and side loading - both with roll outbody trays
- Optional hydraulic trolley is available
- Internal lighting
- Lockable doors
- Heavy duty castors for easy moving
- Automatic defrosting
- Fully insulated chamber walls and doors

Head Office Phone (02) 9604 3911
Head Office Fax (02) 9725 1706

Email info@thermoline.com.au
Web www.thermoline.com.au

 **Thermoline**
S C I E N T I F I C
H I G H E R S T A N D A R D S I N S C I E N C E

PRODUCT DETAILS

These mortuary cabinets are a product from the Fiocchetti Scientific Division. Two models are available, one with two front opening doors (one above the other) and the other with two side loading doors (one above the other). Both chambers are constructed inside and out with stainless steel and have 60mm polyurethane insulation.

The refrigeration unit is a packaged assembly which is located on the top of the cabinet. The cool air is forced down through the interior. The temperature is controlled by a digital controller which has a range of -5°C to +10°C (TMC2-5-2SD) with an optional lower range of -25°C (TMC2-25-2SD) available.

Both units are supplied with two roll out stainless steel body trays. For easy loading, an optional hydraulic trolley is available which can lift from 300mm to 1500mm in height.

Larger chambers also available to carry three, six, nine or twelve bodies.

Optional Accessories	
Hydraulic lift trolley	
Optional lower temperature range in model TMC2-25-S2D down to -25°C	

SPECIFICATIONS

Model	TMC2-5-2SD	TMC2-25-2SD
Body Trays	2	2
External Dimensions (HxWxD mm)	1880x840x2430	
Temperature Range	-5°C to +10°C	-25°C to +10°C
Weight (kg)	480	500

Thermoline Scientific have been manufacturing and distributing high quality laboratory and scientific testing equipment since 1970. Over this time, Thermoline has grown to be a leading brand in the science industry, with our equipment being used in small and large Hospitals, Universities and Research Laboratories across Australia and the Asia Pacific region.

We're proud to say that we are 100% Australian owned and operated.

Head Office Phone (02) 9604 3911

Head Office Fax (02) 9725 1706

Email info@thermoline.com.au

Web www.thermoline.com.au